





Quick Start Guide


Sigfox Access Station Micro SMBS-T4




Package contents




Sigfox Access Station Micro



Passive PoE injector



Power supply adapter
(select the correct plug for your region)



Mounting kits



Ethernet cable




Safety notice

Accessories available separately:



3G or 4G USB dongle



Sealing cover

Before you start

This quick start guide will take you through the few steps required to connect and start using your station.

For detailed installation recommendations and product specifications, please refer to the Product Manual available in several languages from your Sigfox Operator or online at:


micro.sigfox.com

For safety information please refer to the notice included in the box.

To use you Access Station Micro, you will need:

- ✔ Internet connection: either by Ethernet port or compatible 3G/4G USB dongle
- ✔ Indoor 220 / 110 V AC power outlet

Getting to know your station





Installing your station

Step 1 Place your station


Place or fix the Access Station Micro at the desired location. Make sure you leave enough space to access the ports and you can see the side to check the LED color.

Step 2 Connect your station to the Internet

Connect the ethernet cable to the Ethernet port and / or the cellular dongle (if used). For sealing cover addition see instruction in sealing cover pack.




Connect the other end of the Ethernet cable to the PoE injector, and the latter to the wall socket or router.



Step 3 Power on your station

Connect the PoE injector to the power adapter and plug the adapter to a power outlet.


Your station will boot up automatically.



Step 4 Activation / configuration

The activation of the station on the cloud (referred as commissioning) is done by the local Sigfox Operator.

The Access Station Micro is ready and operational as soon as the boot up is done, the connectivity established and the LED is solid green. This should takes less than 2 minutes in normal temperature conditions, and all LED colours depicted below may occur. ✓



Check with your local Sigfox Operator for activation or if any change in the configuration is required.

Understanding the LED of your station

Light is	Meaning	Then ...
Off	No power	Your Access Station Micro is not powered. Please check the PoE power supply is firmly attached.
Red - Solid	Power on	Your Access Station Micro is powering on. If the light remains red after 2 minutes your Access Station Micro may need replacement. Contact the support at your point of purchase.
Green - Flashing	Booting up (30 - 60 sec)	If flashing continues for more than 2 minutes contact your support.
Orange - Flashing	Establishing connectivity	If flashing continues after 1 minute, the Ethernet port or USB dongle may be disconnected. Make sure the internet connection is working.
Orange - Solid	Establishing VPN connection	If the LED color remains after 1 minute, check your network configuration. Otherwise your station may not be registered correctly. Contact your support.
Green - Solid	In Operation	Your Access Station Micro is up and running.
Purple - Solid	Warming up (temp < 0°) Cooling down (temp > 55°C)	External temperature is too extreme. While your station is in cooling/warming mode, it is not in service.

Support

Thank you for choosing the Sigfox Access Station Micro.

For more detailed information, product updates and online manuals please check micro.sigfox.com.

For support, contact your local Sigfox Operator or distributor.

+33 (0)5 82 08 07 10
Bâtiment E-volution
425, rue Jean Rostand
31670 Labège – France
sigfox.com



The information presented is subject to change without notice. Sigfox assumes no responsibility for inaccuracies contained herein. Sigfox and the Sigfox logo are trademarks of Sigfox. All other trademarks are the property of their respective owners. Copyright ©2018 Sigfox. All right reserved.